MEELECTRONICS®

VENTURE

STEREO WIRELESS BLUETOOTH HEADPHONES

model: AF52

USER MANUAL

part of the AIR-FI series

EN

TABLE OF CONTENTS

Product Overview 1
Charging 2
Powering On and Off 2
Pairing with Bluetooth® Devices 3
iPhone®, iPad®, and iPod touch® 3
Android™ Phones and Tablets 3
Computers and Laptops 3
Connecting to Paired Devices 4
Using the Venture Headphones 4
Adjusting Volume 4
Controlling Phone Calls 5
Controlling Media Playback 5
Additional Functionality 6
Using as a Wired Headphone 6
Safety and Care 6
Specifications 6
Troubleshooting 6

VENTURE

MEELECTRONICS®

MEElectronics and its logo are registered trademarks of S2E, Inc. All rights reserved.

iPhone®, iPad®, iPod touch® is a registered trademark of Apple Inc.
Android™ is a registered trademark of Google Inc.
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.
and any use of such marks by MEElectronics is under license. Other trademarks and trade names are those of their respective owners.

PRODUCT OVERVIEW

VENTURE

AF52 Stereo Bluetooth Wireless Headphones



Left Ear Cup

A microphone
B LED indicator
C power on/off button ⏻
D volume down V–
E volume up V+
F 3.5mm audio jack

Right Ear Cup

G mini-USB port for charging
H next track ⏭
I play/pause button ⏯
J previous track ⏮

CHARGING

*** You must completely charge the headset
before the first use ***

Connect the mini USB charging cable to any powered USB port and to the mini USB jack on the right ear cup. The bright red LED indicator will light solid while charging. Charge time is typically 3-6 hours for the first charge and 2-3 hours for subsequent charges. When the battery is fully charged the bright red LED indicator will turn off.

Note: Bluetooth will function when the unit is charging, but leaving the Venture on can increase charge time. The headphones can also be turned off and used with the included audio cable while charging. This will not affect charge time.

When the battery is low, the Venture will produce 4 short tones and two red LED flashes every 20 seconds

TURNING ON AND OFF

a) To turn on, press and hold the Power button for approximately 3 seconds. The Venture will say “power on” and the blue indicator light will flash 2 times.

b) To turn off, press and hold the Power button for approximately 4 seconds. When turning off, the Venture will say “power off” and the red indicator light will flash 2 times.

PAIRING WITH BLUETOOTH® DEVICES

*** It is only necessary to pair your Venture once with each device ***

a) Open the Bluetooth menu* on the device you wish to pair and "search for" or "add" new devices.

b) Make sure the Venture is off and within 1 meter of your device. Initiate pairing mode by pressing the power button for 7 seconds, until you hear "pairing." The LED light on the venture will flash red and blue in an alternating manner. (Note: The Venture will enter standby mode if not paired within 2 minutes.)

c) Wait until you see "Air-Fi Venture" appear on your device

d) Select "Air-Fi Venture" on your device and allow to pair. If your device asks for a pin, enter "0000". Once pairing is complete and a connection is established, the red indicator light will flash 8 times.

If pairing fails, please repeat steps a) through d) above

***Locating the Bluetooth menu:**

iPhone, iPad, and iPod Touch

a) On your device, go to ***Settings***

b) Select ***Bluetooth*** (Bluetooth is under the ***General*** menu in iOS 5.1.1 and older); if Bluetooth is not on, turn it on. The iPhone/iPad/iPod will automatically search for new devices

Android Phones and Tablets

a) On your device, go to ***Settings*** menu

b) Select ***Wireless & Networks*** → ***Bluetooth Settings*** and if Bluetooth is not on, turn it on. Select "Search for Devices" if your phone or tablet does not automatically search for new devices

Computers and Laptops

Visit **www.meelec.com/bluetooth** for pairing, connecting, and audio device setup for computers.

If pairing fails after several tries, please refer to your device's user manual for further information.

CONNECTING TO PAIRED DEVICES

*** The Venture must have been previously paired with your device before you can connect ***

When the Venture is turned on and not in pairing mode, it should automatically connect to last connected device. If the last connected device is not available, the Venture will connect to other paired devices in the order of last connection.

If the Venture does not connect and remains in standby mode, a short press of the Play/Pause button will connect to the last connected device with Bluetooth on and within range.

Notes: On some PC and Mac computers you will need to manually enable Bluetooth audio every time you connect

USING THE VENTURE HEADPHONES

Adjusting Volume

Status	Action	Operation	Notes
No media playing	N/A	The Venture volume cannot be adjusted when media is not playing	N/A
Media playing	Increase volume	Single press or press and hold the Volume Up **V+** button	Volume will adjust on the Venture; the connected device volume is independent. If the volume is not loud enough or too loud, adjust the volume on your device and the Venture. When connected to some computers the volume will be controlled only on the Venture.
	Decrease volume	Single press or press and hold the Volume Down **V–** button	
During a phone call	Increase volume	Single press Volume Up **V+** button	Volume adjustments change the volume on the device, not the Venture.
	Decrease volume	Single press Volume Down **V–** button	

Note: When the volume reaches the minimum or maximum level there will be two short tones.

USING THE VENTURE HEADPHONES (Continued)

Controlling Phone Calls

Status	Function	Operation
Incoming call	Answer a call	Single press the Power ⏻ button
	Reject a call	Press and hold the Power ⏻ button until you hear a long tone
Call in progress	Mute/Hold or Cancel mute/hold	Press and hold the Power ⏻ button until you hear a long tone
	End a call	Single press the Power ⏻ button
Call in progress, phone handset active[1]	Switch from phone handset to Venture	Single press the Power ⏻ button
Call in progress, second incoming call	Answer new call and end current call	Single press the Power ⏻ button
	Answer new call and place the current call on hold	Press and hold the Power ⏻ button until you hear a long tone
One call active, one on hold	Switch to call on hold	Press and hold the Power ⏻ button until you hear a long tone
	End current call and switch to call on hold	Single press the Power ⏻ button

[1] If you answer a call from your phone instead of the headset, most phones will activate the phone handset, not the Venture

Controlling Media Playback

Status	Function	Operation
No media playing[1]	Play media	Press the Play/Pause ►/II button
Media playing	Pause media playback	Press the Play/Pause ►/II button
Either media playing or stopped[2]	Skip to next track	Press the Next ⏭ button
	Fast forward the track	Press and hold the Next ⏭ button
	Restart the track/previous track	Press the Previous ⏮ button
	Rewind the track	Press and hold the Previous ⏮ button

[1] You may need to bring your media app to the screen for the Venture controls to work
[2] Not all media players support this functionality.

Note: If you answer or make a call while listening to media, the media will be paused until the call has ended.

USING THE VENTURE HEADPHONES (Continued)

Additional Functionality

Note: When the volume reaches the minimum or maximum level there will be two short tones.

Action / Status	Button Function	Sounds
Activate voice command / dialing	Single press the Power ⏻ button	Short tone
Redial last phone number	Press and hold the Power ⏻ button until you hear a long tone	Long tone when redial is initiated

USING AS A WIRED HEADPHONE

The Venture comes with a 3.5mm audio jack on the left ear cup and an audio cable for wired use. This allows use with in-flight entertainment devices, devices that don't have Bluetooth or aren't paired, or when the battery is depleted.

The Venture can be used wired while still connected via Bluetooth to another device. Bluetooth audio takes precedence over wired audio; if a Bluetooth device is connected while listening to wired audio, wired audio will partially mute when any audio is transmitted via Bluetooth. Wired audio will resume approximately 20 seconds after the Bluetooth transmission ends.

SAFETY AND CARE

a) When not in use, power the headphones off and store in the included protective pouch.

b) Clean with a soft cloth, damp with diluted soap water solution if necessary. Never use chemical cleaners.

c) There are no user replaceable/reparable parts in the headset. Disassembling it will void your warranty.

d) Do not expose the headphones to liquids. If submersed in water, do not turn the device on until completely dried.
Note: liquid submersion voids the warranty.

e) Battery performance will be severely decreased when stored in extreme temperatures: below -10°C/14°F or above 45°C/113°F.

SPECIFICATIONS

See the Air-Fi Venture product page at **www.meelec.com** for product specifications.

TROUBLESHOOTING

Please visit **www.meelec.com/bluetooth** for the troubleshooting information

MEELECTRONICS®

www.meelec.com